

# CONFIGURACIÓN DE CONTROL REMOTO EQUIPO GDRC DTA3 DTA 101 IDTA 153: Lista de Códigos LCD/Plasma TV's

MARCA	CÓDIGO
ABEX	1575
ACER	1725
ACME	1412
ADA	1402
ADC	1397
ADMIRAL	1406, 1527, 1416, 1613
ADVENT	1733, 1508, 1557, 1566, 1641
ADVENTURA	1564
AIKO	1453
AIWA	1585, 1586, 1614, 1622

AKAI	1498, 1398, 1472, 1700, 1701, 1617, 1687 1689 1702
ALLERON	1446
AMARK	1416
AMTRON	1448
ANAM NATIONA	1448, 1399, 1421, 1437, 1583
AOC	1400, 1401, 1405, 1660, 1410, 1546, 1565, 1577
APEX	1604, 1606, 1605, 1695, 1633
ARCHER	1416
ASPECT	1454
AUDIOVOX	1726, 1727, 1448, 1670, 1690
AXION	1567
BANG & OLUFSEN	1580
BELCOR	1400
BELL & HOWELL	1427, 1444, 1396, 1397

BENQ	1476, 1478, 1494, 1712
BLUESKY	1717, 1536
BRANFORD	1448
BROKSONIC	1538, 1527, 1624, 1632, 1644
BROKWOOD	1400
CANDLE	1400, 1405, 1564, 1404
CAPEHART	1565
CCE	1715
CELEBRITY	1398
CELERA	1604
CENTRIOS	1559
CENTURION	1405
CETRONIC	1437
CHANGHONG	1604, 1633
CINERAL	1453, 1536

CITIZEN	1400, 1405, 1448, 1498, 1502, 1579, 1527, 1397, 1404, 1437, 1453
CLAIRTONE	1410
CLASSIC	1604, 1633, 1437
CLP	1536
CLP CLASSIC	1479, 1488, 1459
COBY	1685, 1692
COLOR VOICE	1406
COLORTYME	1400, 1405, 1406
CONCERTO	1400, 1405
CONCIERGE	1513
CONTEC	1448, 1408, 1410, 1437
CORNEA	1445
CRAIG	1448, 1437
CROSLEY	1457

CROWN	1448, 1437
CTX	1416
CURTIS MATHES	1427, 1498, 1522, 1400, 1405, 1396, 1444, 1502, 1628, 1397, 1411
CXC	1448, 1437
CYBERVISION	1536
DAEWOO	1522, 1400, 1405, 1493, 1401, 1530, 1438, 1532, 1434, 1637, 1475, 1437, 1453, 1413, 1406, 1518, 1414, 1519, 1415
DAYTRON	1400, 1405
DELL	1599, 1424, 1524
DIAMOND VISION	1600, 1649, 1486, 1639
DIGIMATE	1668
DIGISTAR	1670, 1555, 1510, 1508, 1557, 1524, 1671, 1713, 1714
DIMENSIA	1427, 1396
DISNEY	1548, 1527

DUKANE	1454, 1467
DUMONT	1513, 1400
DURABRAND	1579, 1527, 1543, 1607, 1547, 1698, 1525
DYNASTY	1437
DYNEX	1733, 1527, 1743
ELECTROBAND	1398, 1410
ELECTROHOME	1400, 1405, 1617, 1399, 1418
ELEKTRA	1397
ELEMENT	1735, 1676
ELITE VIDEO	1587
EMERSON	1734, 1400, 1405, 1439, 1527, 1444, 1446, 1579, 1448, 1538, 1434, 1522, 1600, 1614, 1615, 1617, 1619, 1620, 1624, 1625, 1638, 1435, 1436, 1437, 1417, 1419, 1420, 1569, 1440, 1421, 1423, 1426, 1428, 1429, 1430, 1432
ENVISION	1741, 1400, 1405, 1469, 1660

ESA	1579
FISHER	1444, 1503, 1621, 1570, 1408
FLUID	1676, 1677, 1678
FUJITSU	1740, 1587, 1446, 1657
FUNAI	1446, 1579, 1448, 1614, 1638, 1464, 1437
FUTURETEC	1448, 1437
GATEWAY	1441
GE	1427, 1500, 1554, 1400, 1405, 1439, 1449, 1396, 1627, 1399, 1517, 1411, 1418, 1447, 1482
GIBRALTER	1513, 1400
GOLDSTAR	1400, 1405, 1401, 1614, 1626, 1408, 1452, 1475, 1546
GPX	1647
GRADIENTE	1664, 1400, 1543, 1722, 1721
GRUNDY	1446, 1448
GUESTVISION	1591

GVISION	1656
HAIER	1476, 1606, 1607, 1547, 1709, 1645
HALLMARK	1400, 1405
HARVARD	1448
HAUPPAUGE	1747
HEWLETT PACKARD	1666, 1655
HISENSE	1738, 1468, 1572, 1606, 1667
HITACHI	1483, 1454, 1534, 1455, 1467, 1400, 1405, 1485, 1653, 1397, 1408, 1456, 1529, 1531, 1533, 1569, 1614
HYUNDAI	1697
ILO	1588, 1682, 1675, 1674, 1537, 1579, 1702, 1689
IMA	1448
IN FOCUS	1396
INFINITY	1457, 1623
INITIAL	1682, 1537, 1684, 1688



INSIGNIA	1743, 1742, 1737, 1733, 1496, 1579, 1607, 1527, 1525, 1508, 1557, 1710, 1638, 1425, 1640, 1751, 1752, 1753
INTEGRA	1571
INTEQ	1513
JANEIL	1564
JBL	1457
JC PENNEY	1427, 1400, 1401, 1405, 1498, 1500, 1502, 1449, 1396, 1482, 1404, 1408, 1411, 1418, 1426, 1447
JCB	1398
JENSEN	1400, 1405, 1525
JVC	1455, 1422, 1587, 1464, 1550, 1616, 1642, 1408, 1460, 1462, 1533
KAWASAKI	1648
SAWASHO	1400, 1405, 1398
KAYPANI	1565
KEC	1437, 1448

KENWOOD	1400, 1405
KLH	1604
KLOSS NOVABEAM	1463, 1564
KOGI	1656
KONKA	1448, 1407, 1412, 1442, 1461, 1496, 1634, 1635, 1425
KTV	1448, 1410, 1417, 1437, 1465
KURAZAI	1397
LASONIC	1600, 1649
LEGEND	1508
LG	1526, 1400, 1445, 1405, 1401, 1545, 1524, 1614, 1626, 1408, 1452, 1475, 1546
LIQUIDVIDEO	1567, 1558
LODGENET	1732, 1427, 1592, 1396, 1397
LOEWE	1601, 1457
LOGIK	1427, 1396, 1397

LUCE	1450
LUXMAN	1400, 1405
LXI	1427, 1400, 1405, 1444, 1457, 1500, 1502, 1396, 1614, 1411
MAGNASONIC	1446
MAGNAVOX	1736, 1457, 1400, 1405, 1573, 1696, 1613, 1623, 1638, 1404, 1463, 1470, 1533
MAJESTIC	1427, 1396, 1397
MARANTZ	1457, 1571, 1400, 1405
MAXENT	1441
MEDION	1603, 1588, 1548
MEGATRON	1400, 1405, 1454
MEI	1410
MEMOREX	1400, 1405, 1444, 1446, 1527, 1427, 1396, 1658, 1621, 1624, 1397, 1632, 1676
MGA	1400, 1401, 1405, 1446, 1408, 1418, 1533, 1570

MIDLAND	1427, 1513, 1449, 1500, 1411
MINTEK	1537
MINUTZ	1447
MISAKAI	1579
MITSUBISHI	1401, 1541, 1446, 1400, 1405, 1617, 1418, 1533, 1570
MONIVISION	1431
MONTGOMERY WARD	1427, 1397, 1396
MOTEVA	1444, 1664
MOTOROLA	1416, 1399
MTC	1400, 1401, 1405, 1498, 1502, 1410
MULTITECH	1448
MULTIVISION	1479
MYRON & DAVIS	1602
NAD	1400, 1405, 1502, 1575

NEC	1750, 1571, 1400, 1401, 1405, 1399, 1406, 1489, 1533
NET TV	1441, 1516
NEXXTECH	1681, 1557
NIKEI	1437
NIKKO	1400, 1405, 1453
NIKO	1705
NORCENT	1606, 1438, 1451
NTC	1453
OLEVIA	1678, 1663, 1703, 1704, 1718
ONCOMMAND	1591, 1723
ONKING	1437
ONWA	1448, 1437
OPTIMUS	1560, 1575, 1629, 1631
OPTOMA	1679

OPTONICA	1416, 1489
ORION	1513, 1527, 1430
PANASONIC	1744, 1561, 1539, 1449, 1560, 1457, 1629, 1631, 1636, 1650, 1399, 1465
PHILCO	1457, 1400, 1401, 1405, 1573, 1407, 1720, 1463, 1470, 1533, 1399, 1404
PHILIPS	1544, 1736, 1457, 1594, 1574, 1598, 1595, 1596, 1597, 1400, 1579, 1573, 1589, 1590, 1476, 1711, 1716, 1623, 1638, 1399, 1404, 1463, 1470, 1481, 1482, 1533
PHILIPS-MAGNAVOX	1457, 1594, 1597, 1573, 1613, 1623
PILOT	1400
PIONEER	1575, 1571, 1467, 1400, 1405, 1484, 1569
PIVA	1683
PLANAR	1658
POLAROID	1739, 1724, 1676, 1572, 1563, 1525, 1670, 1699, 1425
PORTLAND	1400, 1401, 1405, 1530, 1522

PRECISION	1556
PRICE CLUB	1498
PRIMA	1670, 1555, 1508, 1557, 1566
PRINCETON GRAPHICS	1416, 1492
PRISM	1449
PROSCAN	1427, 1500, 1411, 1396, 1552, 1553
PROTON	1582, 1400, 1405, 1661, 1487, 1565, 1576
PROTRON	1668, 1719
PROVIEW	1676, 1677, 1678
PULSAR	1513, 1400
QUASAR	1561, 1539, 1449, 1560, 1457, 1629, 1631, 1399, 1465
RADIO SHACK	1427, 1400, 1443, 1444, 1448, 1560, 1405, 1614, 1627, 1396, 1408, 1436, 1437, 1489
RCA	1427, 1400, 1443, 1449, 1488, 1493, 1495, 1500, 1521, 1581, 1401, 1405, 1396, 1552,

	1553, 1627, 1399, 1411, 1418, 1490, 1506, 1517, 1569, 1577, 1578
REALISTIC	1427, 1400, 1443, 1444, 1448, 1560, 1405, 1396, 1614, 1408, 1436, 1437, 1489
RHAPSODY	1410
RUNCO	1513, 1571, 1504
SAMPO	1516, 1441, 1400, 1405, 1565, 1408
SAMSUNG	1498, 1472, 1471, 1502, 1403, 1405, 1400, 1401, 1480, 1562, 1646, 1628, 1408, 1411, 1475, 1497, 1499
SAMSUX	1405
SAMTRON	1498
SANSUI	1527, 1624, 1632
SANTECA	1584
SANYO	1444, 1491, 1503, 1400, 1621, 1408, 1501, 1570
SCEPTRE	1729, 1695, 1540
SCOTCH	1400, 1405



SCOTT	1702, 1400, 1405, 1446, 1448, 1420, 1430, 1437
SEARS	1427, 1457, 1444, 1446, 1498, 1400, 1405, 1500, 1502, 1503, 1579, 1396, 1505, 1474, 1632, 1638, 1408, 1411, 1570
SELECTRON	1673, 1671, 1672
SEMP	1652
SHARP	1474, 1515, 1458, 1416, 1400, 1405, 1613, 1620, 1402, 1489, 1514
SHOGUN	1400
SIGNATURE	1427, 1396, 1397, 1419
SIMPSON	1404
SONIC	1410
SONY	1520, 1409, 1398, 1466, 1630, 1542
SOUNDESIGN	1400, 1405, 1446, 1448, 1404, 1437
SOVA	1654, 1686
SOYO	1693, 1694

SPECTRA	1600
SPECTRAVISION	1593
SQUAREVIEW	1579
SSS	1400, 1448, 1437
STAR SIGHT	1459
STARLITE	1448
SUPERSCAN	1505, 1474, 1638
SUPERSONIC	1647
SUPRA	1400, 1477
SUPREMACY	1564
SUPREME	1398
SVA	1606, 1602
SYLVANIA	1457, 1400, 1405, 1527, 1579, 1573, 1533, 1614, 1638, 1404, 1466, 1470, 1533, 1551
SYMPHONIC	1448, 1579, 1614, 1638, 1420

SYNTAX	1678, 1703, 1704
TANDY	1416
TATUNG	1476, 1588, 1399
TECHNICS	1449
TECHWOOD	1400, 1405, 1449
TEKNIKA	1427, 1400, 1401, 1405, 1446, 1448, 1498, 1502, 1560, 1396, 1564, 1397, 1404, 1408, 1437
TELECATION	1509
TELERENT	1427, 1396, 1397
TERA	1400, 1576
TEVION	1588
TMK	1400, 1405
TOSHIBA	1549, 1568, 1502, 1512, 1571, 1498, 1444, 1489, 1560, 1618, 1628, 1632, 1643, 1408, 1489, 1509, 1533
TRUTECH	1680, 1707, 1691

UNIVERSAL	1447, 1482
VENTURER	1745
VICTOR	1455
VIDEOCON	1728
VIDTECH	1400, 1401, 1405
VIEWSONIC	1741, 1441, 1467, 1665, 1706
VIKING	1564
VIORE	1669
VIZIO	1731, 1730, 1476, 1505, 1535, 1662, 1445, 1651, 1748, 1749, 1746, 1608, 1609, 1610, 1611, 1612
WARDS	1427, 1457, 1400, 1401, 1405, 1446, 1396, 1463, 1470, 1482, 1489, 1511, 1447, 1397, 1404, 1420
WESTINGHOUSE	1535, 1507, 1708, 1398
WHITE WESTINGHOUSE	1493, 1522, 1530, 1528, 1659, 1614, 1475
YAMAHA	1560, 1400, 1401, 1405

ZENITH

1513, 1405, 1445, 1473, 1485, 1530, 1454,  
1523, 1433, 1504, 1526, 1543, 1459, 1400,  
1527, 1613, 1614, 1616, 1620, 1623, 1624,  
1626, 1628, 1419, 1434, 1397, 1453